


GUBI

ASSEMBLY INSTRUCTIONS


for

Silk Lantern
Wall Lamp



CONTENTS.

LANTERN WALL LAMP

					
x1	x1	x1	x1	x2	x1

Installation.


Unbox the base.

1A. Remove the top screw.


1B. Detach the wall bracket.



1A.




1B.



Mark the installation position. Use a level to ensure straight installation.

Depending on the wall type, use the appropriate plugs. Fasten the wall bracket using the two screws.

1C.




Attach the wall base to the hook on the bracket.


2A. Guide the top toward the wall until it's flush.

2B. Secure the wall base with the top screw.

2A.




2B.




Shade.

- 1. Unfold the shade and ensure that the silk shade is securely attached to the wooden frame.
- 2. Locate the wooden ring with grooves. This functions as the top part. Insert the brass hanger into the available grooves.


1A.




1B.



2A.







2B.



Attachment.

- 1. Insert Type A bulb into the socket. Not included.
- 2. Pull the shade up parallel to the cable. Once you reach the desired height, snap it into place.





CARE INSTRUCTIONS

Wipe the parts with a dry or damp cloth that has been soaked in warm water. Only use soft cloths for wiping and polishing; never use sponges or steel wool. Do not use abrasive household cleaners.

Avoid acidic or alkaline cleaning materials, glass cleaner, and household ammonia.

SILK

Dust regularly with a soft brush or cloth. Spot clean with a slightly damp, white cloth. Do not immerse in water, as this may cause spots or damage. Keep the shade out of direct sunlight. Silk is fragile.

TROUBLESHOOTING

If the lamp does not light up, turn off the power. Check the bulb for a broken filament. Replace the bulb, if necessary, and then turn the lamp on. If the lamp still does not light up, contact the local dealer's customer service. If this lamp's external flexible cable or cord is damaged, a qualified electrician must replace it to avoid a hazard.

TECHNICAL INFORMATION

Light sources:

EU: 1 x E27

US: 1 x E26

Max. 6W LED. Turn off the power when changing the light bulb.

Isolation class II. This lamp is not approved for outdoor use or use in damp or wet rooms (IP20).

ENVIRONMENTAL PROTECTION

Electrical products must not be thrown out with regular trash. Instead, they must be taken to a communal collection point for environmentally friendly disposal, in accordance with local regulations. Contact your local authorities or retailer for recycling advice. The packaging material is recyclable. Dispose of the packaging in an environmentally friendly manner and make it available for the recycling collection service. Do not incinerate it.



For enquiries contact GUBI A/S - CVR: 17940384

Orientkaj 18-20. 2150 Nordhavn. Copenhagen, Denmark

T +45 69 15 60 60 – order@gubi.dk

GUBI.COM