AUTO AIR VALVE FULL FLOW

#	DESCRIPTION	PART #
o	VALVE, AUTO AIR, 1-1/2" FULL FLOW, (NORMALLY CLOSED)	888-2123-108PB-L
o	VALVE, AUTO AIR, 2" FULL FLOW, (NORMALLY CLOSED)	888-2123-109PB
d	VALVE, AUTO AIR, 1-1/2"L & 2" FULL FLOW,REPAIR KIT INCLUDES # 1, 2, 3, 5, 7, 11, 13, 20 & 21	888-2123-00999PB
24	VALVE, AUTO AIR, 1-1/2"L & 2" FULL FLOW, SPRING	888-2123-10924PB



