Apply masking tape to soft-touch area prevents damage during button removal

(A) OFF

START STOP



2) Using a plastic pry tool, press down on soft-touch surface & pop switch loose



3) Carefully remove switch from dashboard







5) Carefully lift retaining tabs & remove switch back-plate from face-plate



6) Seporate two halfs of switch, be carefull not MODO to drop printed circut board from back plate BARGAINS

7) Using tweezers depress internal clips to free button from housing

MOD III BARGAINS

8) Front of button should now be free and and fall out of face-plate

(A) OF



9) Align button tabs into faceplate housing

ENGIN



10) Carefully press button into face-plate, button snaps into position (you'll hear two clicks)



BARGAINS

11) Reassemble back-plate to face-plate







14) Enjoy your new Red Start-Stop Engine Button MCCO BARGAINS



This Page Is Left Intentionally Blank