
User's manual	Manual del usuario	Manuel de l'utilisateur
Customer Service US: 1-800-645-2986	Servicio de atención al Cliente US: 1-800-645-2986	Service à la clientèle Canada: 888-645-2986

Gondola Shelving, End Cap

Model(s): 243470/243471/243472/243473/243474/243475/243476/243477/243478




Note: Owner/Operator must read and understand this instruction manual before using the GONDOLA SHELVING


Rev A: 4/22/25

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243470

No	Global PN	Description	Quantity
1	243414	Upright 54"	2
2	243418	Base Bracket 16"	2
3	243436	Base End Trim Pair 16" -Black	1
4	243422	Bottom Rail 36"	1
5		Top Rail 36"	1
6		Center Rail 36"	1
7	243427	Pegboard Back Panel 34-17/32" x 47-13/16" H	2
8	243444	Base Shelf 36" x 16"	1
9	243440	Upright End Trim 54"	2
10		Tube Cap for Upright	2
11	243420	Closed Base Front 36" -Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243471

No	Global PN	Description	Quantity
1	243415	Upright 60"	2
2	243418	Base Bracket 16"	2
3	243436	Base End Trim Pair 16" - Black	1
4	243422	Bottom Rail 36"	1
5		Top Rail 36"	1
6		Center Rail 36"	1
7	243428	Pegboard Back Panel 34-17/32" x 53-13/16" H	2
8	243444	Base Shelf 36" x 16"	1
9	243441	Upright End Trim 60"	2
10		Tube Cap for Upright	2
11	243420	Closed Base Front 36" - Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243472

No	Global PN	Description	Quantity
1	243416	Upright 72"	2
2	243418	Base Bracket 16"	2
3	243436	Base End Trim Pair 16" -Black	1
4	243422	Bottom Rail 36"	1
5		Top Rail 36"	1
6		Center Rail 36"	1
7	243429	Pegboard Back Panel 34-17/32" x 65-13/16" H	2
8	243444	Base Shelf 36" x 16"	1
9	243442	Upright End Trim 72"	2
10		Tube Cap for Upright	2
11	243420	Closed Base Front 36" -Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243473

No	Global PN	Description	Quantity
1	243414	Upright 54"	2
2	243418	Base Bracket 16"	2
3	243436	Base End Trim Pair 16" -Black	1
4	243423	Bottom Rail 48"	1
5		Top Rail 48"	1
6		Center Rail 48"	1
7	243431	Pegboard Back Panel 46-17/32" x 47-13/16" H	2
8	243446	Base Shelf 48" x 16"	1
9	243440	Upright End Trim 54"	2
10		Tube Cap for Upright	2
11	243421	Closed Base Front 48" -Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243474

No	Global PN	Description	Quantity
1	243415	Upright 60"	2
2	243418	Base Bracket 16"	2
3	243436	Base End Trim Pair 16" -Black	1
4	243423	Bottom Rail 48"	1
5		Top Rail 48"	1
6		Center Rail 48"	1
7	243432	Pegboard Back Panel 46-17/32" x 53-13/16" H	2
8	243446	Base Shelf 48" x 16"	1
9	243441	Upright End Trim 60"	2
10		Tube Cap for Upright	2
11	243421	Closed Base Front 48" -Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243475

No	Global PN	Description	Quantity
1	243416	Upright 72"	2
2	243418	Base Bracket 16"	2
3	243436	Base End Trim Pair 16" -Black	1
4	243423	Bottom Rail 48"	1
5		Top Rail 48"	1
6		Center Rail 48"	1
7	243433	Pegboard Back Panel 46-17/32" x 65-13/16" H	2
8	243446	Base Shelf 48" x 16"	1
9	243442	Upright End Trim 72"	2
10		Tube Cap for Upright	2
11	243421	Closed Base Front 48" -Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243476

No	Global PN	Description	Quantity
1	243414	Upright 54"	2
2	243419	Base Bracket 22"	2
3	243437	Base End Trim Pair 22" -Black	1
4	243423	Bottom Rail 48"	1
5		Top Rail 48"	1
6		Center Rail 48"	1
7	243431	Pegboard Back Panel 46-17/32" x 47-13/16" H	2
8	243447	Base Shelf 48" x 22"	1
9	243440	Upright End Trim 54"	2
10		Tube Cap for Upright	2
11	243421	Closed Base Front 48" -Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended




Global PN: 243477

No	Global PN	Description	Quantity
1	243415	Upright 60"	2
2	243419	Base Bracket 22"	2
3	243437	Base End Trim Pair 22" -Black	1
4	243423	Bottom Rail 48"	1
5		Top Rail 48"	1
6		Center Rail 48"	1
7	243432	Pegboard Back Panel 46-17/32" x 53-13/16" H	2
8	243447	Base Shelf 48" x 22"	1
9	243441	Upright End Trim 60"	2
10		Tube Cap for Upright	2
11	243421	Closed Base Front 48" -Black	1
12		Leveling Wrench	1


⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.

GONDOLA SHELVING END CAP

TOOLS NEEDED: Leveling Wrench(included)



Two Person Assembly Recommended



Global PN: 243478

No	Global PN	Description	Quantity
1	243416	Upright 72"	2
2	243419	Base Bracket 22"	2
3	243437	Base End Trim Pair 22" -Black	1
4	243423	Bottom Rail 48"	1
5		Top Rail 48"	1
6		Center Rail 48"	1
7	243433	Pegboard Back Panel 46-17/32" x 65-13/16" H	2
8	243447	Base Shelf 48" x 22"	1
9	243442	Upright End Trim 72"	2
10		Tube Cap for Upright	2
11	243421	Closed Base Front 48" -Black	1
12		Leveling Wrench	1

⚠ The loaded capacity of the shelf depends on the shelves. Please refer to the shelf loaded capacity limits on page 11.


GONDOLA SHELVING END CAP

Shelf Load Capacity

SHELF TYPE	SHELF WIDTH	SHELF ANGLES	SHELF DEPTH 16" RECOMMENDED UNIFORM LOAD CAPACITY	SHELF DEPTH 22" RECOMMENDED UNIFORM LOAD CAPACITY
Base Shelf (Deck)	36"	Deck	600 LBS (275 KGS)	800 LBS (365 KGS)
	48"	Deck	600 LBS (275 KGS)	800 LBS (275 KGS)
Multi Position Shelf	36"	Flat	500 LBS (230 KGS)	500 LBS (230 KGS)
		17° Downslant	250 LBS (115 KGS)	250 LBS (115 KGS)
	48"	Flat	500 LBS (230 KGS)	500 LBS (230 KGS)
		17° Downslant	250 LBS (115 KGS)	250 LBS (115 KGS)

NOTE:
Reduce capacities shown by 30% w hen only the front half of the shelf/deck is loaded or by 50% if the shelf/deck is less than 36" wide.

GONDOLA SHELVING END CAP




NOTE: Do not adjust leveling legs on base brackets or uprights currently.

Step 1.

Push ②bracket into ①upright slots from two sides, then push down to secure. (It is necessary to secure the spring on the ②bracket.)


Repeat for the other set of ② bracket and ①upright assembling.



Step 2.

Two persons work together. One person lifts the previously assembled uprights and base brackets assembly. The other person installs ④bottom rail and ⑥center rail onto the ①upright, and then install ⑪the closed base front.


GONDOLA SHELVING END CAP



NOTE: ⑬ Splicer rail

and ⑭ top Pegboard

are only used for two-piece back installation.





Step 3.


Insert two pieces of ⑦Pegboard from top to bottom, make sure the board is secured by slot on the rails, then install ⑬ splicer rail on the top of the ⑦Pegboard, secured on the two side uprights, after that insert two pieces of ⑭ top pegboard from top onto ⑬ splicer rail.

IMPORTANT! If ceiling height is not adequate to drop panels from top, you can pull the upright apart to make an angle, let the upside opening larger and then install the Pegboard from the front. The pegboard can be bent slightly, but don't use too much force, otherwise the pegboard will break.

GONDOLA SHELVING END CAP








Step 4.


Install 2pcs③base end trim according to the detailed picture. Insert ⑤top rail onto the top, then insert 2pcs ⑨upright trim from top to bottom, finally assemble 2pcs ⑩ top cap with the upright.

IMPORTANT! Base end trim must slide behind the flanges on base bracket at the front and rear side, and be seated properly. Base bracket end trim must be installed before base decks.



Step 5.

Install ⑧based desk onto the Base Bracket, after the installation, if it is not level, use the wrench to adjust the height of the levelers on Upright and Base Bracket, until the shelf is straight and level.



IMPORTANT! Base bracket end trim must be installed before base decks.