

kiddie t**ö**tes

Cleaning & Care Instructions

Thank you for purchasing kiddietotes! We are excited to welcome you family and value your trust in us. We know you will enjoy your fully functional backpack that will look great for years to come.

To help you keep your kiddietotes looking fresh and clean, please follow the cleaning care instructions below:

HARD SURFACES:

Wipe with a slightly damp cloth and a mild solution of dish soap or laundry detergent with warm water. Let air dry in a cool ventilated space. Do not dry in direct sunlight as this may cause fading of the backpack.

PLUSH:

Gently spot clean with a slightly damp cloth and a mild solution of dish soap or laundry detergent with warm water. Let air dry in a cool ventilated space. Do not dry in direct sunlight as this may cause fading of the backpack.

NYLON/SPANDEX:

Gently spot clean with a slightly damp cloth and a mild solution of dish soap or laundry detergent with warm water. Be mindful to not vigorously rub the fabric as this may tear mesh compartments. Let air dry in a cool ventilated space. Do not dry in direct sunlight as this may cause fading of the backpack.

ODOR:

Sprinkle baking soda inside backpack and let it sit for 30 minutes to 1 hour. Tap out baking soda and clear out any excess powder with a blow dryer on the lowest and coolest setting. If there is still an odor present, you can repeat the process and/or use a fabric freshener on soft fabrics.

NOTE:

Do not put your kiddietotes into a washing machine for laundering, as this may cause breakage of internal and external parts. Do not use a brush, or corrosive cleaners, to clean backpack as this may cause discoloration and dull the vibrant colors.