

black box POCKET+


Programming Guide

Step 1: Make sure the radio is powered on.

Step 2: Insert USB cable into computer and connect your radio.
Part numbers: POCKET-USB or BANTAM-USB. The USB charging port will not program the radio.




Step 3: From the top menu bar, select Setting > Set Com and choose the port the radio is connected.
Trial and error may be needed on Step 5 if you have multiple COM options



Step 4: Confirm proper radio connection by selecting **Program > Read from Radio**.

Failure at this point means the radio wasn't connected properly or is connected to a different COM port.

Step 6: You should now see a table with frequency information. You can manipulate this data to program custom frequencies and codes. After making your changes, select **File > Save As** and save your file. You can use the file to quickly program Pocket radios in the future.



Step 7: Write your frequencies to the radio by selecting **Program > Write to Radio**.