


PADDLE HANDLE - ELECTRIC DEADMAN CONTROL HANDLE

#	DESCRIPTION	PART #
	PADDLE HANDLE CONTROL, ELECTRIC (DEADMAN CONTROL HANDLE)	290-349
1	BOOT, PUSH BUTTON (D-HANDLE ELEC)	534-541
2	SWITCH, PUSH BUTTON ASSY (D-HANDLE ELEC)	534-531
3	STRAIN RELIEF FITTING	888-7117-504PB
4	MALE TWIST-LOCK CONNECTOR, 2 PRONG	10-354



www.pirate-brand.com
(317) 829-0147 • (800) 892-6223
2719 Tobey Dr. Indianapolis, IN 46219