




BOTTOM LED

BOTTOM LED

12V IN



THIS WILL TURN THE TOP LED ON WHEN THE SWITCH IS ACTIVATED AND TUEN THE LED OFF WHEN THE SWITCH IS OFF. WE NORMALLY PULL 12v + AT TERMINAL 6 FROM A KEYED IGNITION SOURCE TO ILLUMINATE THE LOWER LED. THIS WAY YOU CAN TURN YOUR ACCESSORY ON WITHOUT HAVING TO TURN THE KEY ON.

