

SECTION 1000-GENERAL SPECIFICATIONS

CARPET TILE INSTALLATION INSTRUCTIONS:

Failure to follow these guidelines for installation may void of Product Warranty. Any variance from any of the following instructions will become the responsibility of the installer and not the manufacturer, and shall void all otherwise applicable warranties.

1. Site Conditions

Carpet Tiles are not intended for installation on walls or wet surfaces. We recommend the following conditions before installation: The best environment in which the carpet is to be installed is the temperature between 65° F and 95° F (18° C and 35° C) and the relative humidity between 10% and 65%. A pH range of 5-9 is satisfactory.

2. Floor Preparation

SECTION 1000-GENERAL SPECIFICATIONS

CARPET TILE INSTALLATION INSTRUCTIONS CONT.

8. Carpet Installation

Tiles are printed on the back with arrows showing pile direction. Start from the intersection point in the center of the floor. Install the tiles in one quadrant using the chalk lines as guidelines. Fill in the area between the two chalk lines using the stair step method. Continue to install tiles in a stair step or pyramid pattern, starting at the center point. Check to make sure the tiles are properly aligned at edges during the installation. Fit the tiles tightly together by sliding them together and press into the adhesive (Fig. 2).

Refer to the installation direction instruction on sample folder.

