



CT-3215 Hutch Mount Double Pail Holder Kit Assembly Instructions for Installation



Calf-Tel Hutch Mount Double Pail Holder Kit Bill of Material:

Item	Item Number	Description	Qty
1	CTPHD	Double Inside Pail Holder	1
2	CH-3214	Pail Holder Stem	1
3	CT-9500	Pail Holder Assembly Hardware	1

Tools Needed:

1. Flat Head Screw Driver
2. 7/16" Deep Well Socket
3. Ratchet

Installation Instructions:

Step 1: Attach Pail Holder Support Stem to Double Pail Holder: Secure support stem to pail holder with 1 washer and 1 nut.

Inside View



Step 2: Secure Double Pail Holder to Hutch: Slide pail holder over lip of side feeding opening and push studs through holes in the hutch. Tighten nuts and washers onto studs on outside of hutch.

Outside View



Step 3: Fasten Pail Holder Stem to Hutch: Install stem under hutch lip using 1-1/4" screw. Tighten nut and washer on outside of hutch.