

INSTALLATION:

- I. The bell should be mounted a minimum of 8 ft. from the floor or as close to the ceiling as possible.
- 2. Remove the gong
- 3. Connect the wiring (see diagram).
- 4. Mount bell mechanism to backbox (bell mechanism must be mounted with the striker pointing down).
- 5. Reinstall the gong (be sure that the gong positioning pin, in the mechanism housing, is in th hole in the gong).
- 6. Test all bells for proper operation that they can be heard where required (bells must be heard in all areas as designated by the authority having jurisdiction).

800-854-1015

www.argco.com

FAX 760-727-3270