



NOTE:

- For Installation on
- a. Dry-Walls
- b. Glass-Partitions and Metal Partitions as well as
- material)

Please see separate installation instructions of respected installation kits.

Required Tools

- a. Spanner (preferably ring end) 13mm (similar to 1/2")
- b. Laser/Spirit level
- c. Phillips head screwdriver
- length for 1" thick particle board)





© 2021 by Bobrick Washroom Equipment, Inc.

Form No. 9806-9807-75 ii Issued 6/21/21 Printed in U.S.A.

In the U.S.A.: BOBRICK WASHROOM EQUIPMENT, INC. Los Angeles: 6901 Tujunga Ave., North Hollywood, CA 91605-6213: Tel: (818) 982-9600, FAX: (818) 503-1102 New York: 200 Commerce Drive, Clifton Park, NY 12065-1350; Tel: (518) 877-7444, FAX: (518) 877-5029, or e-mail: customerservice@bobrick.com

In Canada: BOBRICK WASHROOM EQUIPMENT COMPANY

45 Rolark Drive, Scarborough, Ontario M1R 3B1 • Eastern Canada: Tel: (877) 423-6555 • FAX: (877) 423-8555 • Western Canada: Tel: (877) 423-6444 • FAX: (877) 423-8444 4

fino collection


Installation Instructions for Grab Bars B-9806 and B-9807

c. "back-to-back-installation of two grab bars against each other from opposite sides of partition-panels (glass and any other partition

d. six pcs. #10 sheet metal screws, flat head, stainless steel, length depending on application (e.g. 1/2" length for 1/2" CL-partitions and 1"



"Exploded" overview of the grab bar flange:



5. Fit Bolt (M8 Screw) & Knurled Washer through Half-Moon Washer.

- 1. Securely fix flange-bases to panel/wall at correct pitch (18"/24"/36"/42") using the appropriate fixings (see also PCD-Pitch Circle diameter). Ensure a minimum of 6" from corners/returns so that a spanner can be used later.
- 2 Use base flange as a template to mark drilling holes on the wall with a pencil.


Base flange has 3 pcs. of 5.0mm (3/16") mounting holes, equally spaced 120° apart on a 38.0mm (1-1/2") Bolt/Pitch Circle Diameter (BCD/PCD).

Bobrick recommends using #10 Sheet metal screws, flat head, length depending on application. Screw heads want to be below flush. Use a level to assist in laying out. Screw- and drilling examples :

a. #10 sheet metal screw, flat head, 1/2" screw length for 1/2" CL-partitions, 3/16" predrill

b. #10 sheet metal screw, flat head, 1" length for 1" thick particle board, 9/64" predrill

3. Fit the flange covers on both flanges with the bevelled edge facing out.



6. With the slots in the tube facing down, pass the thread of the bolt (M8 Hex Screw) through the slot in either end of the tube from the inside. Hold the tube and gently twist to help the bolt (M8 Hex screw) pass through the slot. Repeat for other end of the tube while keeping the slots facing down to avoid losing the part just fitted. Make sure the shape of the half-moon washer is aligned with the inside diameter of the tube.

7. Push both threaded bolts (M8 Hex Screws) into flange end hole and finger tighten using the knurled washer on the bolt (M8 Hex Screw). Ensure the radius on the pillar matches the radius of the tube.

Tighten both ends with the ring end of a 13mm spanner making sure not to damage the tube with the spanner. Fit end caps making sure to locate the screwdriver release recess facing down out of casual observation.



