

<p>1.</p> <p>TOOLS REQUIRED</p>	<p>2.</p> <p>REMOVE STOCK PAD</p>	<p>3.</p> <p>MAKE SURE KICK-EEZ PAD IS LARGER THAN STOCK</p>
<p>4.</p> <p>COVER BACK SIDE OF PAD WITH TAPE</p>	<p>5.</p> <p>REATTACH KICK-EEZ PAD</p>	<p>6.</p> <p>SCORE TAPE EDGE TO MARK BOUNDARIES</p>
<p>7.</p> <p>REMOVE EXCESS TAPE</p>	<p>8.</p> <p>REMOVE PAD</p>	<p>9.</p> <p>ATTACH TO GRINDING JIG</p>
<p>10.</p> <p>MATCH THE COMB ANGLE WITH PAD & TIGHTEN JIG</p>	<p>11.</p> <p>GRIND PAD TO TAPE BOUNDARY, HEAL SIDE FIRST</p>	<p>12.</p> <p>GO SLOW, TAKE YOUR TIME, TAKE SMALL AMOUNTS OFF</p>
<p>13.</p> <p>CLEAR VISUAL FIELD OFTEN</p>	<p>14.</p> <p>NOW THAT THE HEAL HAS BEEN GROUND..</p>	<p>15.</p> <p>MOVE ONTO THE TOE HALF</p>
<p>16.</p> <p>REPEAT ANGLE MATCHING ON TOE SIDE</p>	<p>17.</p> <p>REPEAT GRINDING PROCESS</p>	<p>18.</p> <p>FINISH ROUGH SAND</p>
<p>19.</p> <p>REMOVE FROM JIG</p>	<p>20.</p> <p>REMOVE TAPE</p>	<p>21.</p> <p>TIP: ADD OIL TO SCREW</p>
<p>22.</p> <p>FINISH SAND WITH OIL & 220+ GRIT SANDPAPER</p>	<p>23.</p> <p>SAND UNTIL DESIRED FINISH</p>	<p>24.</p> <p>ENJOY KICK-EEZ</p>